

## WIRING DIAGRAMS

ADP provides the cable designated for connecting the sensor. Wires required for the RDS controller installation are field supplied.

The Refrigerant Detection System Controller supports all split gas furnace installations. Wiring diagrams are provided for several common split furnace system configurations to identify exact wire types and terminal locations.

For additional wiring diagrams for accessories, zoning, and other system types please go to: [www.adpnow.com](http://www.adpnow.com) or contact ADP technical support at [adp.techsupport@adpnow.com](mailto:adp.techsupport@adpnow.com).


**NOTICE**


For proper installation connect only the indoor unit to the blue colored terminals on the RDS controller. The outdoor unit and thermostat are to be wired only to the black colored terminals.

